Sheng Jay Automation Technologies Co., Ltd.

No. 12, Wulin St., Shulin City, Taipei 238, Taiwan, R.O.C. (Shulin Industrial Park)

Tel: +886-2-2684-1569 Fax: +886-2-2684-1567 E-mail: service@sja.com.tw

SJ-5291 Mini GPS Tracker

GPRS+GPS

User's Manual

Version History

Date	Version	Description of change	Author
2009-3-10	1.0		Thomas

Content

1. Introductions 4
1.0 Overview 4
1.1 Features 5
1.2 Applications 5
1.3 Optional Software 5
1.4 General Specifications 6
1.5 GSM/GPRS Specification 6
1.6 GPS Specification 6
1.7 LED Indicator 7
1.7.1 Main Power Indicator 7
1.7.2 Backup Battery Charger Indicator 7
1.7.3 GPS Status Indicator 7
1.7.4 GSM/GPRS Status Indicator 7
1.8 Mechanical specifications 8
1.9 Environment specification 8
1.10 Package List 8

2. Hardware Installation 9
2.1 Precaution 9
2.2 SIM Card Installation 9
2.3 Power Supply Installation 10
2.4 LED Status Indication 10
2.5 Check Mini GPS Tracker by SMS 11
2.6 Mini GPS Tracker Setting 11
3. Server setup and Software Installation 14
3.1 Overview 14
3.2 Requirements 14
3.3 Software Setup 15

1. Introductions

1.0. Overview

SJ-5291 Mini GPS Tracker is a versatile and economical platform for mobile positioning applications. It integrates SJA GPS module with Quad-band 850/900/1800/1900GSM/GPRS communication module and powerful microcontroller all onto a single board.

It is enclosed in a solid casing for easy installation. SJ-5291 provides reliable Real Time GPS positions anytime anywhere in the world, providing the correct position and status from remote locations onto computer displayed maps. The operation modes including continuous tracking, position lock and car perform tracking with no extra wires needed. With additional Power switch button and SOS buttons which is for sending emergency call. All configurations can be set via SMS or by application software via USB interface.

The SJ-5291 transmit NMEA message to 24-hrs Control Center by Packet-Switch for monitoring through either GPRS or SMS massage system. Control center sets command by sending commands for monitoring through GSM system or Internet access.

1.1. Features

- Supports Quad band 850/900/1800/1900 MHZ operation
- GPRS multi-slot class 10 and mobile station class B
- Integrated TCP/IP stacks
- SMS transfer via GSM/GPRS
- Remote control via SMS
- Real-time GPS tracking
- Real-time vehicle status monitoring
- Dual data communication capability through GPRS and SMS
- RS232 interface with USB connector for Setup
- Power supply and low battery detection acknowledge
- 4 LED indicators for power, battery charger in progress, GSM/GPRS and GPS status
- Built-in 1000 mAh Recharge battery

1.2 Applications

- Security (women and children safety protection)
- Commercial vehicle monitor and driver performance monitor
- Rental car monitoring and theft recover
- Emergency (ambulance and fire engine)
- Bike riding and hiking

1.3 Optional Software

- Data logger in PC
- Up to 4 SMS numbers for emergency report
- Self geofence and out of range alert
- Speed detection
- GPS reporting internal user programmable
- System status report (power, battery)
- Security administration

1.4 General Specifications

Parameter	Specification
Power Supply	5 VDC
Power Consumption	GSM class 12 hours
	GPRS class 8.5 hours
Firmware Upgrade	USB
Function Setting	USB
SIM card type	1.8V, 3V
LED Status Indicator	Main Power/ Battery charge in progress/GPRS/GPS
Serial port interface	USB

1.5 GPRS/GSM Specifications

Parameter	Specification
Frequency	Quad band 850MHz/900MHz/1800MHz/1900MHz
Output Power	Class 4(2W) for EGSM 850 and 900 Class 1(1W) for GSM 1800 and 1900
Protocol support	TCP
GPRS Multi-slot	Class 10
GPRS Mobil station	Class B
Coding scheme	CS1,CS2,CS3,CS4
PBCCH support	Yes
USSD support	Yes
Downlink/ Uplink max.	85.6Kbps/42.8 kbps

1.6 GPS Specifications

Parameter	Specification
Transmission data	NMEA 0183 Ver3.01
Receiver channels / Fixing method	SirRF III 20 channels
Acquisition sensitivity	-137 dBm
Tracking sensitivity	-158 dBm
Receiver frequency	1575.42MHz L1 C/A Code
Accuracy (1)Position (2)Datum	 5m CEP WGS-84
Time To First Fix	45Sec(typ)

(1)Cold start (2)Warm start (3)Hot start	35Sec(typ) 1Sec(typ)
Dynamic condition	4G (39.2m/sec^2)
Interface	UART
Operational Limits (1) Altitude (2) velocity	 < 18,000m < 500m/s
Bit rate	9600 bps
Start bit	1 bit
Stop bit	1 bit
Data bit	8 bit
Parity	None
Output sentences	GPGGA/GPGSA/GPGSV/GPRMC
Refresh time	1Sec

1.7 LED Indicator

1.7.1 Main Power Indicator

For the Main Power Indicator through **red** LED, detailed information is shown in the following table.

LED mode	**Operation status**
On	Main power on
Off	Main power off

1.7.2 Backup Battery Charger Indicator

For the Main Power Indicator through **yellow** LED, detailed information is shown in the following table.

LED mode	**Operation status**
On	Backup battery charge in progress
Off	Backup battery charge complete

1.7.3 GPS Status Indicator

For the GPS status indicator through **green** LED, detailed information is shown in the following table.

LED mode	**Operation status**
On	Searching satellite
1 sec On /1 sec Off	Tracking satellite

1.7.4 GSM/GPRS Status Indicator

For the GPRS/GSM status indicator through **green** LED, detailed the information is shown in the following table.

LED mode	**Operation status**
On	GSM/GPRS is not running
3000 ms On/3000 ms Off Flashing	Indicates GPRS data transfer:
1 sec On /1 sec Off Flashing	GPRS does not find the network / GSM running

1.8 Mechanical specification

Parameter	**Specification**
Dimension	56mm(L) X 44mm(W) X 21 mm(H)
Weight	61.6 g

1.9 Environment specification

Parameter		**Specification**
Temperature	Operating	- 20℃ to +60℃
	Storage	-40℃ to +80℃

1.10 Package List

Before getting started, please make sure you have the following devices, programs and accessories.

1. **SJ-5291 device x 1**
2. **CD-ROM which contains server program and related documents x 1**
3. **Mini USB cable x 1**

2. Hardware Installation

2.1. Precaution

1) Check if all parts are included as the Package List.

2) Prepare a SIM card and use a mobile phone to unblock the SIM PIN code. Be sure that if use the SIM card can dial out or receive calls without problem.

2.2 SIM Card Installation

Insert the SIM card by sliding it into the card holder slot, as shown in the figure.

PS. If you want to replace the SIM card, press the push button and pull out the holder.

2.3 Power Supply Installation

Simply connect the power cord to the power cord connector on the front side of the device.

There is a power switch on the front side of the device, and you can turn it on/off by this switch.

2.4 LED Status Indication

1) After connected the power cord connector and turn the power switch on, the Power and Battery LED will light up.
2) The Bule LED of GPS will flash while being active.
3) The Green LED of GSM/GPRS will flash when sending or receiving messages.
4) Being during charging status, the Red LED will light up.

2.5 Check Mini GPS Tracker by SMS

1) After the Hardware Installation is done. You can send the" $IQUPOS,000000 " by SMS to the installed device, and the position information included the latitude and longitude data will be response to you by the received device.



Subscribe send SMS to Mini GPS Tracker The Mini GPS Tracker will response the GPS information to it by SMS

2.6 Mini GPS Tracker Setting

Requirements

Please using Mini GPS Tracker with power supply amd connect with PC with Windows XP interface by Mini USB Cable.

1. Run set up program



2. Enter Password(Default setting: 000000) and press Connect Button. The program will search port automaticly When connet successly, wait for the number of Mini GPS Tracker deviceID.





3. Press Read All Button will read through all Mini GPS Tracker parameters



4. Press Read Button, can read the single setting value



5. Adjust the parameter needed, press Set Button to finish setting



6. Also can adjst all parameter, then press Set All Button to finish all setting



7. If you forget MINI GPS TRACKER passowrd , you can press “Reset Default” Button.

About parameter

1. Device ID : set up MINI GPS TRACKER program ID, it must be letters and cipher, special charaters ($@^#&*! etc.) is not accepted
2. Password : set up password of MINI GPS TRACKER program with cipher
3. Phone: set up MINI GPS TRACKER to sending SMS number, four setting is avalaible
4. Band : Select GSM System, (900 /1800 Mhz or 850 /1900Mhz)
5. GPRS : set up GPRS function starting
6. Server IP: set up server IP and Port
7. APN String: set up GPRS APN String、UserName、Password, please contact SIM provider
8. Time Interval: set up span time when GPS information transfer via GPRS to Server, range between 10~999 seconds
9. IO : six IO is avaible to used,

   When using Input ,it can detect outside signal

   When using Output, can be controlled via GPRS and SMS to export signal

3. Server setup and Software Installation

3.1 Overview

The Mini GPS Tracker contains the GSM/GPRS module and will send the location information to the Server.

The Server should be installed on a stand-alone computer as a middle ware to control and manage several MINI GPS TRACKER.

Meanwhile, the client Viewer can be installed on other computers as a supervisor over the client/server architecture.

3.2 Requirements

1) Make sure the SIM card has been installed into the Mini GPS Tracker, and the GPRS function is not blocked.
2) **Fix IP Address** is required. The MINI GPS TRACKER will send the GPS data and necessary information to the
3) Server by GPRS.

   PS: Test Server IP is 60.250.90.244 and port is 2500, it can connect to Test Server for your testing.
4) The PC system requirements as the following:
   - Operating system: Windows XP. Or Vista
   - .Net Framework 3.5
   - CPU: Intel P4 2.0 above.
   - Hard disc: 2.0GB above.
   - Memory: 2GB above.
   - Ether Port (LAN Port): 10/100MBPS above.
   - Fix IP
5) Please ensure SIM Card's PIN Code is disable.
6) Ensure GPRS service is available as well as APN, APN Name, APN Password.

3.3 Software Setup

1. Run Server.exe. Program



2. Click Setting Tab and Setting Server IP, Port, Language etc…and Press “Save” Button.



3. Press “Star” Button, will Run Timer and Data Receiver.



4. Press Start Sever button to start Server, A Button: increase ID and D Button delete ID

5. When Mini GPS Tracker transfers GPS back to Server, it is clear that Mini GPS TrackerID pattern in list becomes green from grey

6. Click “Show Map “ Tab and select ID from the list , pattern change to Green which can be click “google Map” and use Google Map track MINI GPS TRACKER location

Information
Google Map
Google Earth
Simulate GPS Rece
Zoom 14
COM Port COM3
Show All
Asia
Europe
Atlantic Ocean
Africa
South America
Indian Ocean
Australia
Antarctica
POWERED BY Google
檢視較大的地圖

7. Use historical logger function, Click Track Recorded Tab



8. Select date, ID, starting and finishing time, Map Zoom, Timer, then press Show Path to show recorded path.



9. Other Function:

1. Report: I/O Alarm、SOS、Low Battery Status
2. Show Map on Google Earth
3. Simulate GPS Receiver: Show Map on Other Navigate Software.
4. Remote Command: Control or Setting MINI GPS TRACKER via GPRS(Internet)

Q&A

Q1: After sending SMS " $IQUPOS,000000", but not sending SMS back.

A1:

1. Check if GSM LED light is flashing
2. Check if GSM Antenna is connecting and placed with good signal.
3. Check if PIN CODE has been canceled.
4. Check if GSM SYSTEM set up correctly. (900/1800 Mhz or 850/1900Mhz)
5. Check the last month rental fee has been paid or not.

Q2: GSM is working well, but GPRS is not working.

A2:

1. Check if GPRS is flashing slowly.
2. Check if GPRS setting is On
3. Check APN parameter is correct. if APN parameter setting is wrong, SIM Card will restarted repeatedly.
4. Confirm GPRS service has started. (2G / 2.5G GPRS internet, not wap)

Q3: GSM signal and GPRS connection are working, but MINI GPS TRACKER data could not send to Server.

A3:

1. Check Server IP and Port in MINI GPS TRACKER are the same with IP and Port for Server.
2. Check setting of Server software is correct. Internal IP have to set up NAT in router.
3. Check if Port is set up for expectant in antivirus program and fire wall.

Q4: Could not find out MINI GPS TRACKER on maps.

A4:

1. Check if GPRS has been started. (GSM LED flashing slowly)
2. Check GPS LED is flashing.
3. Confirm Server IP and MINI GPS TRACKER setting are correct.

Q5: How long is Battery working time?

A5: Build-in 1700mAh Battery with working hour 12~13.

Q6: Tracker Setting software could not be execute or showing Wrong Message.

A6: Confirm .Net framework 3.5 has been set up or download from website below.

http://www.microsoft.com/downloads/details.aspx?FamilyId=333325FD-AE52-4E35-B531-508D977D32A6&displaylang=en

Q7: Tracker Setting software could be execute, but it could not find out device.

A7:

1. Confirm there is not other RS232 or USB to RS232 connecting with PC.
2. Power for MINI GPS TRACKER has been started.
3. USB Cable connection is correctly.
4. Confirm COM Port device is shown in Device Manager.